



The Synchronization Experts.



MANUAL

GNS165DHS / GNS165DAHS

DIN Rail GNSS Receiver

May 8, 2024

Meinberg Funkuhren GmbH & Co. KG

Table of Contents

1	Imprint	1
2	Copyright and Liability Exclusion	2
3	Presentation Conventions in this Manual	3
3.1	Conventions for the Presentation of Critical Safety Warnings	3
3.2	Secondary Symbols Used in Safety Warnings	4
3.3	Conventions for the Presentation of Other Important Information	4
3.4	Generally Applicable Symbols	5
4	Important Safety Information	6
4.1	Appropriate Usage	6
4.2	Product Documentation	7
4.3	Safety during Installation	8
4.4	Grounding the Device	9
4.5	Electrical Safety	10
4.5.1	Special Information for Devices with AC Power Supply	12
4.5.2	Special Information for Devices with DC Power Supply	12
4.6	Safety when Maintaining and Cleaning the Device	13
4.7	Battery Safety	13
5	Important Product Information	14
5.1	CE Marking	14
5.2	UKCA Marking	14
5.3	Ensuring the Optimum Operation of Your Device	14
5.4	Maintenance and Modifications	15
5.4.1	Replacing the Battery	15
5.4.2	Replacing the Fuse	16
5.5	Disposal	17
6	Meinberg Customer Portal - Software and Documentation	18
7	General information about GNS165/DAHS	19
8	GNS Features	21
8.1	Time Zone and Daylight Saving	21
8.2	Pulse outputs	22
8.3	Asynchronous Serial Ports	22
8.4	Time code outputs	23
8.4.1	Introduction	23
8.4.2	Generated Time Codes	23
8.4.3	Time Code Generation	24
8.4.4	Time Code Format According to IRIG Standard	25
8.4.5	Time Code Format According to AFNOR Standard	26
8.4.6	Structure of CF Segment in IEEE1344 Code	27
8.5	DCF77 Emulation	28
9	Installation	29
9.1	Technical data GNS165/DAHS Chassis	29
9.2	Power supply	29
9.3	40dB Multi GNSS L1 Timing Antenna with Integrated Lightning Protection	30

9.3.1	GNSS Antenna for Fixed-Location Installation	30
9.3.2	GNSS Antenna for Mobile Applications	32
9.4	Powering Up the System	33
9.5	Meinberg Device Manager	34
10	The Front Panel Layout	36
10.1	Front Panel Connectors GNS165/DAHS	36
10.2	Status LEDs	36
10.3	Assignment of the terminal block	37
10.4	Assignment of the DSUB connectors	38
10.5	Antenna Input: GNSS Reference Clock	39
10.6	DCF77 Simulated Output (-62 dBm)	40
10.7	Time Code AM Output	40
10.8	DC Power Supply Connector	41
10.9	AC/DC Power Supply Connector	42
10.10	Fuse	43
11	Technical Specifications GNS Receiver	44
11.1	Technical Specifications: 40 dB Multi GNSS Antenna	46
11.2	Technical Specifications: RV-76G GPS/GLONASS Antenna for Mobile Applications	47
11.3	Technical Specifications: MBG-S-PRO Surge Protector	48
11.4	Connection Data DFMC-connector	49
11.5	Time Strings	50
11.5.1	Meinberg Standard Time String	50
11.5.2	SAT Time String	51
11.5.3	NMEA 0183 String (RMC)	52
11.5.4	NMEA 0183 String (GGA)	53
11.5.5	NMEA 0183 String (ZDA)	54
11.5.6	Uni Erlangen String (NTP)	55
11.5.7	Computime Time String	57
11.5.8	SYSPLEX-1 Time String	58
11.5.9	Format of the SPA Time String	59
11.5.10	RACAL Standard Time String	60
11.5.11	Meinberg GPS Time String	61
11.5.12	ION Time String	62
11.5.13	ION Blanked Time String	63
11.5.14	IRIG-J Timecode	64
11.6	Oscillator specifications	65
12	Meinberg Device Manager	66
13	RoHS Conformity	68
14	Declaration of Conformity for Operation in the European Union	69
15	Declaration of Conformity for Operation in the United Kingdom	70

1 Imprint

Meinberg Funkuhren GmbH & Co. KG
Lange Wand 9, 31812 Bad Pyrmont, Germany

Phone: + 49 (0) 52 81 – 93 09 – 0
Fax: + 49 (0) 52 81 – 93 09 – 230

Website: <https://www.meinbergglobal.com>
Email: info@meinberg.de

Date: May 8, 2024

2 Copyright and Liability Exclusion

Except where otherwise stated, the contents of this document, including text and images of all types and translations thereof, are the intellectual property and copyright of Meinberg Funkuhren GmbH & Co. KG ("Meinberg" in the following) and are subject to German copyright law. All reproduction, dissemination, modification, or exploitation is prohibited unless express consent to this effect is provided in writing by Meinberg. The provisions of copyright law apply accordingly.

Any third-party content in this document has been included in accordance with the rights and with the consent of its copyright owners.

A non-exclusive license is granted to redistribute this document (for example, on a website offering free-of-charge access to an archive of product manuals), provided that the document is only distributed in its entirety, that it is not modified in any way, that no fee is demanded for access to it, and that this notice is left in its complete and unchanged form.

At the time of writing of this document, reasonable effort was made to carefully review links to third-party websites to ensure that they were compliant with the laws of the Federal Republic of Germany and relevant to the subject matter of the document. Meinberg accepts no liability for the content of websites not created or maintained by Meinberg, and does not warrant that the content of such external websites is suitable or correct for any given purpose.

While Meinberg makes every effort to ensure that this document is complete, suitable for purpose, and free of material errors or omissions, and periodically reviews its library of manuals to reflect developments and changing standards, Meinberg does not warrant that this specific document is up-to-date, comprehensive, or free of errors. Updated manuals are provided at www.meinbergglobal.com and www.meinbergsupport.com.

You may also write to techsupport@meinberg.de to request an updated version at any time or provide feedback on errors or suggested improvements, which we are grateful to receive.

Meinberg reserves the right to make changes of any type to this document at any time as is necessary for the purpose of improving its products and services and ensuring compliance with applicable standards, laws & regulations.

3 Presentation Conventions in this Manual

3.1 Conventions for the Presentation of Critical Safety Warnings

Warnings are indicated with the following warning boxes, using the following signal words, colors, and symbols:



Caution!

This signal word indicates a hazard with a **low risk level**. Such a notice refers to a procedure or other action that may result in **minor injury** if not observed or if improperly performed.



Warning!

This signal word indicates a hazard with a **medium risk level**. Such a notice refers to a procedure or other action that may result in **serious injury** or even **death** if not observed or if improperly performed.



Danger!

This signal word indicates a hazard with a **high risk level**. Such a notice refers to a procedure or other action that will very likely result in **serious injury** or even **death** if not observed or if improperly performed.

3.2 Secondary Symbols Used in Safety Warnings

Some warning boxes may feature a secondary symbol that emphasizes the defining nature of a hazard or risk.



The presence of an "electrical hazard" symbol is indicative of a risk of electric shock or lightning strike.



The presence of a "fall hazard" symbol is indicative of a risk of falling when performing work at height.



This "laser hazard" symbol is indicative of a risk relating to laser radiation.

3.3 Conventions for the Presentation of Other Important Information

Beyond the above safety-related warning boxes, the following warning and information boxes are also used to indicate risks of product damage, data loss, and information security breaches, and also to provide general information for the sake of clarity, convenience, and optimum operation:



Important!

Warnings of risks of product damage, data loss, and also information security risks are indicated with this type of warning box.



Information:

Additional information that may be relevant for improving efficiency or avoiding confusion or misunderstandings is provided in this form.

3.4 Generally Applicable Symbols

The following symbols and pictograms are also used in a broader context in this manual and on the product.



The presence of the "ESD" symbol is indicative of a risk of product damage caused by electrostatic discharge.



Direct Current (DC) (*symbol definition IEC 60417-5031*)



Alternating Current (AC) (*symbol definition IEC 60417-5032*)



Grounding Terminal (*symbol definition IEC 60417-5017*)



Protective Earth Connection (*symbol definition IEC 60417-5019*)



Disconnect All Power Connectors (*symbol definition IEC 60417-6172*)

4 Important Safety Information



The safety information provided in this chapter as well as specific safety warnings provided at relevant points in this manual must be observed during every installation, set-up, and operation procedure of the device, as well as its removal from service.

Any safety warnings affixed to the device itself must also be observed.

Any failure to observe this safety information, these safety warnings, and other safety-critical operating instructions in the product documentation, or any other improper usage of the device may result in unpredictable behavior from the product, and may result in injury or death.

Depending on your specific device configuration and installed options, some safety information may not be applicable to your device.

Meinberg accepts no responsibility for injury or death arising from a failure to observe the safety information, warnings, and safety-critical instructions provided in the product documentation.

It is the responsibility of the operator to ensure that the product is safely and properly used.

Should you require additional assistance or advice on safety-related matters for your product, Meinberg's Technical Support team will be happy to assist you at any time. Simply send a mail to techsupport@meinberg.de.

4.1 Appropriate Usage



The device must only be used appropriately in accordance with the specifications of the product documentation! Appropriate usage is defined exclusively by this manual as well as any other relevant documentation provided directly by Meinberg.

Appropriate usage includes in particular compliance with specified limits! The device's operating parameters must never exceed or fall below these limits!

4.2 Product Documentation

The information in this manual is intended for readers with an appropriate degree of safety awareness.

The following are deemed to possess such an appropriate degree of safety awareness:

- **skilled personnel** with a familiarity with relevant national safety standards and regulations,
- **instructed personnel** having received suitable instruction from skilled personnel on relevant national safety standards and regulations



Read the product manual carefully and completely before you set the product up for use.

If any of the safety information in the product documentation is unclear for you, do **not** continue with the set-up or operation of the device!

Safety standards and regulations change on a regular basis and Meinberg updates the corresponding safety information and warnings to reflect these changes. It is therefore recommended to regularly visit the Meinberg website at <https://www.meinbergglobal.com> or the Meinberg Customer Portal at <https://meinberg.support> to download up-to-date manuals.

Please keep all product documentation, including this manual, in a safe place in a digital or printed format to ensure that it is always easily accessible.

Meinberg's Technical Support team is also always available at techsupport@meinberg.de if you require additional assistance or advice on safety aspects of your system.

4.3 Safety during Installation



This rack-mounted device has been designed and tested in accordance with the requirements of the standard IEC 62368-1 (*Audio/Video, Information and Communication Technology Equipment—Part 1: Safety Requirements*). Where the rack-mounted device is to be installed in a larger unit (such as an electrical enclosure), additional requirements in the IEC 62368-1 standard may apply that must be observed and complied with. General requirements regarding the safety of electrical equipment (such as IEC, VDE, DIN, ANSI) and applicable national standards must be observed in particular.

The device has been developed for use in industrial or commercial environments and may only be used in such environments. In environments at risk of high environmental conductivity ("high pollution degree" according to IEC 60664-1), additional measures such as installation of the device in an air-conditioned electrical enclosure may be necessary.

If the unit has been brought into the usage area from a cold environment, condensation may develop; in this case, wait until the unit has adjusted to the temperature and is completely dry before setting it up.

When unpacking & setting up the equipment, and before operating it, be sure to read the information on installing the hardware and the specifications of the device. These include in particular dimensions, electrical characteristics, and necessary environmental conditions.

Fire safety standards must be upheld with the device in its installed state—never block or obstruct ventilation openings and/or the intakes or openings of active cooling solutions.

The device with the highest mass should be installed at the lowest position in the rack in order to position the center of gravity of the rack as a whole as low as possible and minimize the risk of the rack tipping over. Further devices should be installed from the bottom, working your way up.

The device must be protected against mechanical & physical stresses such as vibration or shock.

Never drill holes into the device to mount it! If you are experiencing difficulties with rack installation, contact Meinberg's Technical Support team for assistance!

Inspect the device housing before installation. The device housing must be free of any damage when it is installed.

4.4 Grounding the Device



In order to ensure that the device can be operated safely and to meet the requirements of IEC 62368-1, the device must be correctly connected to the protective earth conductor via the protective earth terminal.

If an external grounding terminal is provided on the chassis, it must be connected to the grounding busbar for safety reasons before connecting the power supply. This ensures that any possible leakage current on the chassis is safely discharged to earth.



The screw, washer, and toothed lock washer necessary for mounting the grounding cable are provided on the grounding terminal of the chassis. A grounding cable is not included with the device.



Please ensure that your grounding cable has a thickness of 1.5 mm² or greater, that you use a suitable grounding terminal or lug, and that the connection is properly crimped!

4.5 Electrical Safety

This Meinberg product is operated at a hazardous voltage.

This system may only be set up and connected by skilled personnel, or by instructed personnel who have received appropriate technical & safety training from skilled personnel.

Custom cables may only be assembled by a qualified electrician.

Never work on cables carrying a live current!

Never use cables or connectors that are visibly damaged or known to be defective! Faulty, defective, or improperly connected shielding, connectors, or cables present a risk of injury or death due to electric shock and may also constitute a fire hazard!

Before operating the device, check that all cables are in good order. Ensure in particular that the cables are undamaged (for example, kinks), that they are not wound too tightly around corners, and that no objects are placed on the cables.

Cables must be laid in such a way that they do not present a tripping hazard.

The power supply should be connected using a short, low-inductance cable. Avoid the use of power strips or extension cables if possible. If the use of such a device is unavoidable, ensure that it is expressly rated for the rated currents of all connected devices.

Never connect or disconnect power, data, or signal cables during a thunderstorm! Doing so presents a risk of injury or death, as cables and connectors may conduct very high voltages in the event of a lightning strike!


Device cables must be connected or disconnected in the order specified in the user documentation for the device. Connect all cables only while the device is de-energized before you connect the power supply.

Always pull cable connectors out at **both** ends before performing work on connectors! Improperly connecting or disconnecting this Meinberg system may result in electric shock, possibly resulting in injury or death!

When pulling out a connector, **never** pull on the cable itself! Pulling on the cable may cause the plug to become detached from the connector or cause damage to the connector itself. This presents a risk of direct contact with energized components.



5-Pin MSTB Connector



3-Pin MSTB Connector




Illustration: Lock screws on an MSTB plug connector; in this case on a LANTIME M320

Ensure that all plug connections are secure. In particular, when using plug connectors with lock screws, ensure that the lock screws are securely tightened. This is especially important for power supply connectors where 3-pin or 5-pin MSTB connectors with lock screws are used (see illustration).

Before the device is connected to the power supply, the device housing must be grounded by connecting a grounding cable to the grounding terminal of the device.

When installing the device in an electrical enclosure, it must be ensured that adequate clearance is provided, minimum creepage distances to adjacent conductors are maintained, and that there is no risk of short circuits.

Protect the device from the ingress of objects or liquids!

If the device malfunctions or requires servicing (for example, due to damage to the housing, power supply cable, or the ingress of liquids or objects), the power supply may be cut off. In this case, the device must be isolated immediately and physically from all power supplies! The following procedure must be followed in order to correctly and reliably isolate the device:

- Pull the power supply plug from the power source.
- Loosen the locking screws of the MSTB power supply plug on the device and pull it out of the device.
- Contact the person responsible for your electrical infrastructure.
- If your device is connected to one or more uninterruptible power supplies (UPS), the direct power supply connection between the device and the UPS solution must be first be disconnected.



4.5.1 Special Information for Devices with AC Power Supply



This device is a Protection Class 1 device and may only be connected to a grounded outlet (TN system).

For safe operation, the installation must be protected by a fuse rated for currents not exceeding 20 A and equipped with a residual-current circuit breaker in accordance with applicable national standards.

The appliance must only ever be disconnected from the mains power supply via the mains socket and not from the appliance itself.

Make sure that the power connector on the appliance or the mains socket is readily accessible for the user so that the mains cable can be pulled out of the socket in an emergency.

Non-compliant cabling or improperly grounded sockets are an electrical hazard!

Only connect the appliance to a grounded shockproof outlet using a safety-tested mains cable designed for use in the country of operation.

4.5.2 Special Information for Devices with DC Power Supply



In accordance with IEC 62368-1, it must be possible to disconnect the appliance from the supply voltage from a point other than the appliance itself (e.g., from the primary circuit breaker).

The power supply plug may only be fitted or dismantled while the appliance is isolated from the power supply (e.g., disconnected via the primary circuit breaker).

Power supply cables must have adequate fuse protection and have an adequate wire gauge size (1 mm² – 2.5 mm² / 17 AWG – 13 AWG)

The power supply of the device must have a suitable on-demand disconnection mechanism (i.e., a switch). This disconnection mechanism must be readily accessible in the vicinity of the appliance and marked accordingly as a disconnection mechanism for the appliance.

4.6 Safety when Maintaining and Cleaning the Device



Only use a soft, dry cloth to clean the device.

Never use liquids such as detergents or solvents to clean the device! The ingress of liquids into the device housing may cause short circuits in the electronic circuitry, which in turn can cause a fire or electric shock!

Neither the device nor its individual components may be opened. The device or its components may only be repaired by the manufacturer or by authorized personnel. Improperly performed repairs can put the user at significant risk!

In particular, **never** open a power supply unit or module, as hazardous voltages may be present within the power supply device even after it is isolated from the upstream voltage. If a power supply unit or module is no longer functional (for example due to a defect), it can be returned to Meinberg for repair.

Some components of the device may become very hot during operation. Do not touch these surfaces!

If maintenance work is to be performed on the device and the device housing is still hot, switch off the device beforehand and allow it to cool.

4.7 Battery Safety



The integrated CR2032 lithium battery has a service life of at least ten years.

Should it be necessary to replace the battery, please note the following:

- The battery may only be replaced by the same type or a comparable type recommended by the manufacturer.
- The battery may only be replaced by the manufacturer or authorized personnel.
- The battery must not be exposed to air pressure levels outside of the limits specified by the manufacturer.

Improper handling of the battery may result in the battery exploding or in leakages of flammable or corrosive liquids or gases.

- **Never** short-circuit the battery!
- **Never** attempt to recharge the battery!
- **Never** throw the battery in a fire or dispose of it in an oven!
- **Never** dispose of the battery in a mechanical shredder!

5 Important Product Information

5.1 CE Marking

This product bears the CE mark as is required to introduce the product into the EU Single Market.



The use of this mark is a declaration that the product is compliant with all requirements of the EU directives effective and applicable as at the time of manufacture of the product.

These directives are listed in the EU Declaration of Conformity, appended to this manual as Chapter 14.

5.2 UKCA Marking

This product bears the British UKCA mark as is required to introduce the product into the United Kingdom (excluding Northern Ireland, where the CE marking remains valid).



The use of this mark is a declaration that the product is in conformity with all requirements of the UK statutory instruments applicable and effective as at the time of manufacture of the product.

These statutory instruments are listed in the UK Declaration of Conformity, appended to this manual as Chapter 15.

5.3 Ensuring the Optimum Operation of Your Device

- Ensure that ventilation slots are not obscured or blocked by dust, or else heat may build up inside the device. While the system is designed to shut down safely and automatically in the event of temperature limits being exceeded, the risk of malfunctions and product damage following overheating cannot be entirely eliminated.
- The device is only deemed to be appropriately used and EMC limits (electromagnetic compatibility) are only deemed to be complied with while the device housing is fully assembled in order to ensure that requirements pertaining to cooling, fire safety, electrical shielding and (electro)magnetic shielding are upheld.

5.4 Maintenance and Modifications



Important!

Before performing any maintenance work on or authorized modification to your Meinberg system, we recommend making a backup of any stored configuration data (e.g., to a USB flash drive from the Web Interface).

5.4.1 Replacing the Battery

Your device's clock module is fitted with a lithium battery (type CR2032) that is used to locally storage almanac data and sustain operation of the real-time clock (RTC) in the reference clock.

This battery has a life of at least ten years. However, if the device exhibits the following unexpected behaviors, the voltage of the battery may have dropped below 3 V, and the battery will need to be replaced:

- The reference clock has the wrong date or wrong time when the system is started.
- The reference clock repeatedly starts in Cold Boot mode (i.e., upon starting, the system has no ephemeris data saved whatsoever, resulting in the synchronization process taking a very long time due to the need to rediscover all of the visible satellites).
- Some configuration options relating to the reference clock are lost every time the system is restarted.

In this case, you should not replace the battery on your own. Please contact the Meinberg Technical Support team, who will provide you with precise guidance on how to perform the replacement.

5.4.2 Replacing the Fuse



Danger!

This equipment is operated at a hazardous voltage.

Danger of death from electric shock!

- The device must be disconnected from the mains! This is done using the physical power switch.
- Once the power switch is OFF, release the lock screws of the power connector (if applicable) and detach the connector.

Meinberg recommends keeping a spare fuse to hand at all times to ensure that a triggering of the integrated fuse does not disrupt the operation of your system for any longer than absolutely necessary. Ensure that it is of the proper type, and that it has the appropriate current and voltage ratings and blow curve. The rated voltage and current values are marked on the device itself next to the fuse compartment.

Fuses are marked with standardized designations in accordance with IEC 60127 to provide information about their specifications. For example, if a fuse is marked *T 2.5 A H 250 V*, it has the following meaning:

- *T*: The blow curve type, in this case *timelag*
- *2.5 A*: The current rating, in this case *2.5 Ampere*
- *H*: The breaking capacity, in this case *high*
- *250 V*: The voltage rating, in this case *250 Volt*

Ensure that the new fuse meets the following requirements and satisfies the specifications printed on the device itself:

Current Type	Labeling Standard	Cooling Material	Blow Curve Type	Dimensions
AC	IEC 60127-compliant	With/without	T (Timelag)	5 x 20 mm
DC	IEC 60127-compliant	With	T (Timelag)	5 x 20 mm

Replacement Process

1. Cut the power supply to the device before disconnecting all signal, antenna, error relay, and serial interface connections from the device. Check that the device is actually de-energized and ensure that it cannot be switched back on!
2. Remove the fuse bracket from the fuse compartment by rotating it anticlockwise using a slotted screwdriver. Replace the fuse and insert the fuse bracket with the new fuse into the fuse compartment. Push it in with the screwdriver and rotate it clockwise until the fuse bracket is securely seated again.
3. Reconnect all cables in the reverse order to how they were disconnected. The power can now be switched back on if appropriate.

5.5 Disposal

Disposal of Packaging Materials



The packaging materials that we use are fully recyclable:

Material	Use for	Disposal
Polystyrene	Packaging frame/filling material	Recycling Depot
PE-LD (Low-density polyethylene)	Accessories packaging, bubble wrap	Recycling Depot
Cardboard	Shipping packaging, accessories	Paper Recycling

For information on the proper disposal of packaging materials in your specific country, please inquire with your local waste disposal company or authority.

Disposal of the Device



This product falls under the labeling obligations of the Waste Electrical and Electronic Equipment Directive 2012/19/EU ("*WEEE Directive*") and thus bears this WEEE symbol. The presence of this symbol indicates that this electronic product may only be disposed of in accordance with the following provisions.



Important!

Do not dispose of the product or batteries via the household waste. Inquire with your local waste disposal company or authority on how to best dispose of the product or battery if necessary.

This product is considered to be a "B2B" product for the purposes of the WEEE Directive and is also classified as "IT and Telecommunications Equipment" in accordance with Annex I of the Directive.


It can be returned to Meinberg for disposal. Any transportation expenses for returning this product (at end-of-life) must be covered by the end user, while Meinberg will bear the costs for the waste disposal itself. If you wish for Meinberg to handle disposal for you, please get in touch with us. Otherwise, please use the return and collection systems provided within your country to ensure that your device is disposed of in a compliant fashion to protect the environment and conserve valuable resources.

Disposal of Batteries

Please consult your local waste disposal regulations for information on the correct disposal of batteries as hazardous waste.

6 Meinberg Customer Portal - Software and Documentation

End users of Meinberg products are provided with technical support, full documentation and software downloads through our Support Centre – all in one place: <https://meinberg.support>



No Registration required

There's no need to register; simply enter your product's serial number at <https://www.meinberg.support> and you'll have everything you need to get your Meinberg system up and running—or perhaps back up and running, as the case may be—with up-to-date installation and reference manuals, downloads for drivers, remote monitoring, configuration tools, and SNMP MIB files, direct links to contact Meinberg's Technical Support team, and the ability to easily request additional files.

The Meinberg Customer Portal vastly simplifies how you access support, software, and documentation, and ensures that you always have the latest versions of downloadable tools and manuals at your disposal.

The installation program for the monitor software "Meinberg Device Manager".

With the help of this programme, Meinberg receivers can be configured via the serial interface and status information of the module can be displayed.

The Meinberg Device Manager software is executable under the following operating systems:

Windows

- Windows 10
- Windows 8.1
- Windows 8
- Windows 7

Linux

- Ubuntu
- Mint Linux
- Debian
- SUSE Linux
- CentOS


The installation programme can also be downloaded at any time via an internet connection:
<https://www.meinbergglobal.com/english/sw/mbg-devman.htm>

A detailed documentation in PDF format can be found here:
<https://www.meinbergglobal.com/download/docs/manuals/english/meinberg-device-manager.pdf>

7 General information about GNS165/DAHS

The Meinberg satellite receiver clock of the GNS165/DAHS series is available with several options. This manual describes the following models:

	20-60 V DC	100-240 V AC	100-240 V DC	Optocoupler outputs	PhotoMos relay outputs
GNS165DHS	x			x	
GNS165DAHS		x	x	x	
GNS165/MOS/DHS	x				x
GNS165/MOS/DAHS		x	x		x



The variants differ in power supply and the type of DC-isolation of the programmable pulse outputs. The differences are described in the relevant chapters, the name GNS165/DAHS is used whenever common features of all types of clocks are specified.

The satellite receiver clock GNS165/DAHS has been designed to provide an extremely precise time reference for the generation of programmable pulses. High precision available 24 hours a day around the whole world is the main feature of the new system which receives its information from the satellites of the Global Positioning System.

The satellites of most **Global Navigation Satellite Systems (GNSS)** like **GPS**, **GLONASS**, and **Galileo** are not stationary but circle round the globe in periods of several hours. Only few GNSS systems like the Chinese **Beidou** system work with stationary satellites. Such systems can only be received in certain regions of the Earth.

GNSS receivers need to track at least four satellites to determine their own position in space (x, y, z) as well as their time offset from the GNSS system time (t). Only if the receiver can determine its own position accurately the propagation delay of the satellite signals can also be compensated accurately, which is requirement to yield an accurate time. If the receiver position can only be determined less accurately then the accuracy

of the derived time is also degraded.

GNSS satellite signals can only be received directly if no building is in the line-of-sight from the antenna to the satellite. The signals can eventually be reflected at buildings, etc., and the reflected signals can then be received. However, in this case the true signal propagation path is longer than expected, which causes a small error in the computed position, which in turn yields less accurate time.

Since most of the satellites are not stationary, the antenna has to be installed in a location with as much clear view of the sky as possible (e.g. on a rooftop) to allow for continuous, reliable reception and operation. Best reception is achieved when the antenna has a free view of 8° angular elevation above the horizon. If this is not possible then the antenna should be installed with the best free view to the sky in direction of the equator. Since the satellite orbits are located between latitudes 55° North and 55° South, this allows for the best possible reception.

All the satellites are monitored by control stations which determine the exact orbit parameters as well as the clock offset of the satellites' on-board atomic clocks. These parameters are uploaded to the satellites and become part of a navigation message which is retransmitted by the satellites in order to pass that information to the user's receiver.

The high precision orbit parameters of a satellite are called ephemeris parameters whereas a reduced precision subset of the ephemeris parameters is called a satellite's almanac. While ephemeris parameters must be evaluated to compute the receiver's position and clock offset, almanac parameters are used to check which satellites are in view from a given receiver position at a given time. Each satellite transmits its own set of ephemeris parameters and almanac parameters of all existing satellites.

8 GNS Features

The GNS is designed for mounting on a DIN rail. The front panel integrates eight LED indicators, an terminal block, two DSUB, two BNC-connectors and one SMA connector. The receiver is linked to the Multi-GNSS Antenna by a coaxial cable with length up to 70 m (when using Belden H155 low loss cable). It is possible to connect up to four receivers to one antenna by using an optional antenna diplexer. Additional outputs are described below

The navigation message coming from the satellites is decoded by GNS's microprocessor in order to track the GNSS system time with an accuracy of better than $\pm 100\text{nsec}$. Compensation of the RF signal's propagation delay is done by automatical determination of the receiver's position on the globe. A correction value computed from the satellites' navigation messages increases the accuracy of the board's TCXO to $\pm 5 \times 10^{-9}$ and automatically compensates the oscillators aging. The last recent value is restored from the battery memory at power-up.

8.1 Time Zone and Daylight Saving

GPS system time differs from the universal time scale UTC (Universal Time Coordinated) by the number of leap seconds which have been inserted into the UTC time scale after GPS has been initiated in 1980. The current number of leap seconds is part of the navigation message supplied by the satellites, so GPS170SV's internal real time is based on UTC.

Conversion to local time including handling of daylight saving year by year can be done by the receiver's microprocessor. As standard the switchover times are set to the values of the European Union (Central Europe). The Manual describes how parameter setting for other locations is done. It is possible to deactivate the automatic switching to/from daylight saving.

8.2 Pulse outputs

The pulse generator of the satellite controlled clock GNS contains three independent channels and is able to generate a multitude of different pulses, which are configured with the software "Meinberg Device Manager". The active state of each channel is invertible, the pulse duration settable between 10 msec and 10sec in steps of 10 msec. In the default mode of operation the pulse outputs are disabled until the receiver has synchronized after power-up. However, you can configure the assembly group to enable the ports immediately after switching on. The pulse outputs are electrically insulated by optocouplers or PhotoMOS relays and are available at the -X1-Interface (DMC-Connector).

The following modes can be configured for each channel independently:

Timer mode:	Three on- and off-times per day per channel programmable
Cyclic mode:	Generation of periodically repeated pulses. A cycle time of two seconds would generate a pulse at 0:00:00, 0:00:02, 0:00:04 etc.
DCF77-Simulation mode:	The corresponding output simulates the DCF77 time telegram. The time marks are representing the local time as configured by the user.
Single Shot Mode:	A single pulse of programmable length is generated once a day at a programmable point of time
Per Sec. Per Min. Per Hr. modes:	Pulses each second, minute or hour
Status:	One of three status messages can be emitted: 'position OK': The output is switched on if the receiver was able to compute its position 'time sync': The output is switched on if the internal timing is synchronous to the GNS-system 'all sync': Logical AND of the above status messages. The output is active if position is calculated AND the timing is synchronized
Time code	The un-modulated IRIG or AFNOR signal of the built in time code generator is made available at the respective output.
Idle-mode:	The output is inactive.
Synthesizer:	Frequency output 0 Hz to 10 MHz

8.3 Asynchronous Serial Ports

One RS-485 serial interface and two asynchronous serial interfaces (RS-232) are available to the user. By default, automatic transmission of a time string via the serial ports is disabled until the receiver has synchronized. However, it is possible to change the device configuration so that serial time strings are always transmitted immediately after power-up.

Transmission speeds, framings and the kind of the time string can be configured separately. The serial ports are sending a time string either once per second, once per minute or on request with ASCII "?" only. The format of the output strings is ASCII, see the technical specifications for details. The corresponding parameters can be set up by the program "Meinberg Device Manager" using serial port COM 0.

8.4 Time code outputs

8.4.1 Introduction

The transmission of coded timing signals began to take on widespread importance in the early 1950's. Especially the US missile and space programs were the forces behind the development of these time codes, which were used for the correlation of data. The definition of time code formats was completely arbitrary and left to the individual ideas of each design engineer. Hundreds of different time codes were formed, some of which were standardized by the "Inter Range Instrumentation Group" (IRIG) in the early 60's. Detailed information about IRIG and other time codes can be found on

<http://www.meinberg.de/english/info/irig.htm>

Except these time codes other formats, like NASA36, XR3 or 2137, are still in use. The module however generates IRIG-B or AFNOR NFS500 only.

Selection of the generated time code is done by using the monitor program.

8.4.2 Generated Time Codes


Besides the amplitude modulated sine wave signal, the board also provides unmodulated DC-Level Shift TTL output in parallel. Thus six time codes are available.

- | | |
|--------------|---|
| a) B002: | 100 pps, DCLS signal, no carrier
BCD time-of-year |
| b) B122: | 100 pps, AM sine wave signal, 1 kHz carrier frequency
BCD time-of-year |
| c) B003: | 100 pps, DCLS signal, no carrier
BCD time-of-year, SBS time-of-day |
| d) B123: | 100 pps, AM sine wave signal, 1 kHz carrier frequency
BCD time-of-year, SBS time-of-day |
| e) B006: | 100 pps, DCLS Signal, no carrier
BCD time-of-year, Year |
| f) B126: | 100 pps, AM sine wave signal, 1 kHz carrier frequency
BCD time-of-year, Year |
| g) B007: | 100 pps, DCLS Signal, no carrier
BCD time-of-year, Year, SBS time-of-day |
| h) B127: | 100 pps, AM sine wave signal, 1 kHz carrier frequency
BCD time-of-year, Year, SBS time-of-day |
| i) AFNOR: | Code according to NFS-87500, 100 pps, wave signal,
1kHz carrier frequency, BCD time-of-year, complete date,
SBS time-of-day, Signal level according to NFS-87500 |
| j) IEEE1344: | Code according to IEEE1344-1995, 100 pps, AM sine wave signal,
1kHz carrier frequency, BCD time-of-year, SBS time-of-day,
IEEE1344 extensions for date, timezone, daylight saving and
leap second in control functions (CF) segment.
(also see table 'Assignment of CF segment in IEEE1344 mode') |
| k) C37.118 | Like IEEE1344 - with turned sign bit for UTC-Offset |


8.4.3 Time Code Generation

By default, time code signals are not output until the GNS165/DAHS is synchronized. However, if the time code signal needs to be output immediately after a reset regardless of the GNSS synchronization state, the "Pulses" enable flag can be set to "Always" in the Meinberg Device Manager software. In this case, the generated time code cannot be considered to be locked to the official UTC second until the GNSS is synchronized.

8.4.4 Time Code Format According to IRIG Standard



8.4.5 Time Code Format According to AFNOR Standard



8.4.6 Structure of CF Segment in IEEE1344 Code

Bit No.	Designation	Description
49	Position Identifier P5	
50	Year BCD encoded 1	Low nibble of BCD-encoded year
51	Year BCD encoded 2	
52	Year BCD encoded 4	
53	Year BCD encoded 8	
54	empty, always zero	
55	Year BCD encoded 10	High nibble of BCD-encoded year
56	Year BCD encoded 20	
57	Year BCD encoded 40	
58	Year BCD encoded 80	
59	Position Identifier P6	
60	LSP - Leap Second Pending	Set until 59s before LS insertion
61	LS - Leap Second	0 = Add leap second, 1 = Remove leap second ^{1.)}
62	DSP - Daylight Saving Pending	Set until 59s before Daylight Saving Time changeover
63	DST - Daylight Saving Time	Set during Daylight Saving Time
64	Timezone Offset Sign	Sign of TZ offset 0 = "+", 1 = "-"
65	TZ Offset binary encoded 1	Offset between IRIG time and UTC time. Encoded IRIG time plus TZ offset equals UTC at all times!
66	TZ Offset binary encoded 2	
67	TZ Offset binary encoded 4	
68	TZ Offset binary encoded 8	
69	Position Identifier P7	
70	TZ Offset 0.5 hour	Set if additional half-hour offset
71	TFOM Time figure of merit	TFOM represents approximate clock error ^{2.)} 0x00 = Clock synchronized, 0x0F = Clock in free-run mode
72	TFOM Time figure of merit	
73	TFOM Time figure of merit	
74	TFOM Time figure of merit	
75	PARITY	Parity of all preceding bits


1.) Current firmware only supports insertion of leap seconds!

2.) TFOM is set to 0 if clock has been able to synchronize since power up. The firmware does not support other codes.

For more information, please refer to the time code specifications.

8.5 DCF77 Emulation

The clock generates TTL level time marks (active HIGH) which are compatible with the time marks spread by the German long wave transmitter DCF77. This long wave transmitter installed in Mainflingen near Frankfurt/Germany transmits the reference time of the Federal Republic of Germany: time of day, date of month and day of week in BCD coded second pulses. Once every minute the complete time information is transmitted. However, the generates time marks representing its local time as configured by the user, including announcement of changes in daylight saving and announcement of leap seconds. The coding scheme is given below:



M	Start of Minute (0.1 s)
R	RF Transmission via Secondary Antenna
A1	Announcement of a Change in Daylight Saving Time
Z1, Z2	Time Zone Identification
	Z1, Z2 = 0, 1: Daylight Saving Time Disabled
	Z1, Z2 = 1, 0: Daylight Saving Time Enabled
A2	Announcement of a Leap Second
S	Start of Time Code Information
P1, P2, P3	Even Parity Bits

Time marks start at the beginning of new second. If a binary "0" is to be transmitted, the length of the corresponding time mark is 100 msec, if a binary "1" is transmitted, the time mark has a length of 200 msec. The information on the current date and time as well as some parity and status bits can be decoded from the time marks of the 15th up to the 58th second every minute. The absence of any time mark at the 59th second of a minute signals that a new minute will begin with the next time mark. The DCF emulation output is enabled immediately after power-up. The time stamps can be provided via pulses outputs. Furthermore, the DCF77 signal is available via a BNC connector as an amplitude-modulated 77.5 kHz carrier. This output can be used for radio clocks as a replacement for a DCF77 antenna.

9 Installation

9.1 Technical data GNS165/DAHS Chassis

The variants of the GNS165/DAHS are available in the following housing dimensions for DIN rail mounting:

Housing:	GNS165DHS:	
	85 mm x 105 mm x 104 mm	(B x H x T)
	GNS165DAHS:	
	125.5 mm x 105 mm x 104 mm	(B x H x T)
	GNS165DAHSx	
	165.5 mm x 105 mm x 104 mm	(B x H x T)
Ambient Temperature:	0...50 °C	
Storage Temperature:	-20...70 °C	
Humidity:	85 %	
Protecting Rate:	IP20	

9.2 Power supply

The variants of the module GNS165/DAHS are designed for following power supply options:

GNS165DHS:	20-60 V DC (DC-insulation 1.5 kV DC)
GNS165DAHS:	100-240 V DC
	100-240 V AC, 50-60 Hz

The voltage feed of the DC variants is done via terminal blocks in the frontpanel of the clock and should have low resistance to minimize spurious emission (EMI).

To avoid potential differences between the signal ground of GNS165/DAHS and a post-connected unit installed on different DIN rails, the signal ground of the clock is insulated from the case.

The case must be grounded by using the rear contact.

9.3 40dB Multi GNSS L1 Timing Antenna with Integrated Lightning Protection

The GPS, GLONASS, Galileo and BeiDou satellites are not stationary but circle round the globe in a period of about 12 hours. They can only be received if no building is in the line-of-sight from the antenna to the satellite, so the antenna unit must be installed in a location with a free view to the sky. The best reception is given when the antenna has a free view of 8° angular elevation above horizon. If this is not possible the antenna should be installed with a mostly free view to the equator because of the satellite courses which are located between latitudes of 55° North and 55° South. If even this is not possible problems occur especially when at least four satellites for positioning have to be found.

The active L1 timing reference antenna is specifically designed for long-lasting, trouble-free deployments for a variety of applications. The low noise, high gain amplifier is well suited to address attenuation issues. The proprietary quadrifilar helix design, coupled with multistage filtering provides superior out-of-band rejection and lower elevation pattern performance than traditional patch antennas.

- Their unique radome shape sheds water and ice, while eliminating problems associated with bird perching.
- This antenna is made of materials that fully comply with provisions stipulated by EU directives RoHS 2002/95/EC.
- The antenna provides integrated lightning protection capability.
- The antenna also features ESD, reverse polarity protection and transit voltage suppression.

A standard coaxial cable with 50 ohm impedance should be used to connect the antenna to the receiver. The max. length of cable between antenna and receiver is 70 meters (H155 – Low-Loss).

See data sheet "40 dB Multi GNSS Timing Antenna with Integrated Lightning Protection" (pctel_gpsl1gl.pdf) or download this document:

[Active Multi GNSS Antenna](#)

http://www.meinbergglobal.com/download/docs/other/pctel_gpsl1gl.pdf

9.3.1 GNSS Antenna for Fixed-Location Installation

The **Multi-GNSS Antenna** is an active GNSS L1 antenna capable of receiving signals from the GPS, GLONASS, Galileo and BeiDou satellite systems. It is very well-suited to fixed-location installations. It is powered by a 5 V DC power supply from the receiver and offers integrated surge protection.

The antenna cable can be up to 70 meters in length if using a suitable low-loss coaxial cable such as Belden H155.

Installation of the GNSS/L1 Antenna




Image: Diagram Showing the Installation of the Multi-GNSS Antenna

Danger!



Do not mount the antenna without an effective fall arrester!



Danger of death from falling!

- Ensure that all necessary safety measures are taken when installing an antenna!
- In particular, never work without an effective fall arrester!

Danger!



Do not work on the antenna system during thunderstorms!



Danger of death from electric shock!

- Do not carry out any work on the antenna system or the antenna cable if there is a risk of lightning strike.
- Do not carry out any work on the antenna system if it is not possible to maintain the prescribed safe distance to exposed lines and electrical substations.

9.3.2 GNSS Antenna for Mobile Applications

The RV-76G is an active GNSS antenna which can receive the signals of the GPS, GLONASS, and Galileo satellite systems. It operates with a 5V DC supply voltage provided by the receiver, and should be preferred for mobile applications. However, the maximum length of the antenna cable is limited depending on the cable type, e.g. 5 meters with RG174/U cable, so this antenna is less suitable for stationary installations.




Figure: Installation drawing RV-76G antenna

Danger!



Do not mount the antenna without an effective fall arrester!

Danger of death from falling!

- Ensure that all necessary safety measures are taken when installing an antenna!
- In particular, never work without an effective fall arrester!

Danger!



Do not work on the antenna system during thunderstorms!

Danger of death from electric shock!

- Do not carry out any work on the antenna system or the antenna cable if there is a risk of lightning strike.
- Do not carry out any work on the antenna system if it is not possible to maintain the prescribed safe distance to exposed lines and electrical substations.

9.4 Powering Up the System

If both the antenna and the power supply have been connected the system is ready to operate. About 10 seconds to 3 minutes after power-up the receiver has warmed up and operates with the required accuracy. If the receiver finds valid almanac and ephemeris data in its battery buffered memory and the receiver's position has not changed significantly since its last operation the receiver can find out which satellites are in view now. Only a single satellite needs to be received to synchronize and generate output pulses, so synchronization can be achieved maximally one to 10 minutes after power-up. After 20 minutes of operation the OCXO is full adjusted and the generated frequencies are within the specified tolerances.

If the receiver position has changed by some hundred kilometers since last operation, the satellites' real elevation and doppler might not match those values expected by the receiver thus forcing the receiver to start scanning for satellites. This mode is called Warm Boot because the receiver can obtain ID numbers of existing satellites from the valid almanac. When the receiver has found four satellites in view it can update its new position and switch to Normal Operation. If the almanac has been lost because the battery had been disconnected the receiver has to scan for a satellite and read in the current almanacs. This mode is called Cold Boot. It takes 12 minutes until the new almanac is complete and the system switches to Warm Boot mode scanning for other satellites.

In the default mode of operation, neither pulse and synthesizer outputs nor the serial ports will be enabled after power-up until synchronization has been achieved. However, it is possible to configure some or all of those outputs to be enabled immediately after power-up. If the system starts up in a new environment (e. g. receiver position has changed or new power supply) it can take some minutes until the OCXO's output frequency has been adjusted. Up to that time accuracy of frequency drops to 10^{-8} reducing the accuracy of pulses to $\pm 3 \mu\text{s}$.

9.5 Meinberg Device Manager


The program serves the configuration of Meinberg Radio Clocks. The software can be run on the operating systems Windows 7 or higher.

Documentation:

<https://www.meinbergglobal.com/download/docs/manuals/english/meinberg-device-manager.pdf>

Download:


<https://www.meinbergglobal.com/english/sw/mbg-devman.htm>



A connection between the system and the program can be produced by serial port. The configurations are described in the "Meinberg Device Manager" documentation.

Connection

The PC should have generated an automatic connection to the clock, select the tab "Search Device". Alternatively, you can use the button "Add Device" to generate a connection to the clock by using the same configure (Port / Baud / Framing).




The "Add Device" dialog box is shown with the following settings:

- Device Type: Other...
- Connection Type: Serial
- Serial Port: COM7
- Baudrate: 19200
- Framing: 8N1
- Custom Alias: GPS165
- Custom Group: Custom Group 1

Buttons: OK, Cancel

Configuration



The "Device Configuration" window is shown with the "Serial Ports" tab selected. The "Satellites" tab is also visible.

Serial Ports Settings

COM0 Baud Rate: 19200
COM0 Framing: 8N1
COM0 String Type: Meinberg Standard
COM0 Mode: Per second

COM1 Baud Rate: 9600
COM1 Framing: 8N1
COM1 String Type: Meinberg Standard
COM1 Mode: Per second

COM2 Baud Rate: 9600
COM2 Framing: 8N1
COM2 String Type: Meinberg Standard
COM2 Mode: Per second

Satellites Status

Status Filter: OK

SVNO	Elevation	Azimuth	Doppler	Status
5	50°	214°	-2088 Hz	OK
7	30°	65°	-2755 Hz	OK
8	12°	44°	331 Hz	OK
13	62°	291°	1597 Hz	OK
15	29°	235°	3071 Hz	OK
21	11°	319°	-96 Hz	OK
28	45°	141°	1926 Hz	OK
30	63°	71°	-1418 Hz	OK

SVNO: -
Elev.: -
Azim.: -

Buttons: Apply All & Close, Revoke All, Cancel & Close

With "Configure Device" various configurations can be carried out on the system. Please note that any changes you make in the settings must always be confirmed with the "Apply Configuration" button. Use the "Restore Configuration" button to reset all settings back to their default values. For more information, please refer to the Meinberg Device Manager manual.

10 The Front Panel Layout


10.1 Front Panel Connectors GNS165/DAHS

Name	Type	Signal	Cable
COM 0, COM 1 COM 2	9pin D-SUB 16pin Terminal	RS-232 RS-485	shielded data line data line
PP_x	16pin Terminal	3 x optocoupler outputs or 3 x photo MOS relay outputs freely programmable with pulses or switching times (PP1, PP2, PP3)	shielded coaxial line
DCF Out	BNC female	77.5 kHz	shielded coaxial line
Time Code AM Out DCLS Out	BNC female 16pin Terminal	3 V _{pp} into 50 Ω RS-422, TTL	shielded coaxial line data line
Antenna	SMA	L1 5 V	shielded coaxial line
Power supply	over 16pin Terminal (DHS standard model) over 5pin Screwterminal (AHS, DAHS)		

10.2 Status LEDs


LED Indicators

TC:	green: if time code RS422 is available
PP 1 – PP 3:	green: if a programmable pulse is available
Init:	blue: while the receiver passes through the initialization phase green: the oscillator has warmed up
Fail:	red: time has not synchronized
Ant:	red: antenna faulty or not connected
Nav:	green: positioning successfully





10.3 Assignment of the terminal block

The pulse outputs are accessible through the terminal block in the front panel. In addition, the power supply of variants GNS165DHS and GNS165/MOS/DHS is connected using two poles of this terminal block. The marking besides the terminal has the following meaning:



+ DC in	positive potential of power supply (GNS165(/AQ//)DHS only)
- DC in	reference potential of power supply (nur GNS165(/AQ//)DHS)
+ PP x	Programmable Pulse (positiv)
- PP x	Programmable Pulse (negativ)
+ RS-485	Serial Time string (positiv)
- RS-485	Serial Time string (negativ)
+ TC_422	Time Code (DCLS) with RS-422 level (positiv)
- TC_422	Time Code (DCLS) with RS-422 level (negativ)
TC_TTL	Time Code (DCLS), TTL into 50 Ω
TC_FET	Time Code (DCLS), field-effect transistor (470 Ω to +5V)
GND	Ground



10.4 Assignment of the DSUB connectors

The serial ports COM 0 and COM 1 are accessible via 9pin DSUB connectors in the frontpanel. These RS-232 interfaces can be connected to a computer by using a standard modem cable. TxD describes the sending, RxD the receiving line of the GNS165/DAHS.

Connector: D-SUB female 9pin


Cable: shielded data line

Assignment:

Pin 2: TxD (transmit)

Pin 3: RxD (receive)

Pin 5: GND (ground)




10.5 Antenna Input: GNSS Reference Clock

Antenna Type:	Multi-GNSS L1 Antenna with integrated Lightning Protection
Receiver Type:	72-Channel Receiver GPS/GLONASS/Galileo/BeiDou
Signal Support:	GPS: L1 C/A (1575.42 MHz) Galileo: E1-B/C (1575.42 MHz) BeiDou: B1I (1561.098 MHz) GLONASS: L1OF (1602 MHz + $k \cdot 562.5$ kHz)

where k represents the channel number (-7 – 6) within the corresponding GLONASS frequency band

Signal Gain:	40 dB
Antenna Gain:	≥ 3.5 dBic / ≥ 3 dBic
Rated Impedance:	50 Ohm
DC Voltage:	5 V (Power Supply via Antenna Cable)
DC Current:	Max. 100 mA
Connector Type:	SMA, Female
Cable Type:	Coaxial Cable, Shielded
Cable Length:	Max. 70 m with Belden H155 Coaxial Cable Max. 150 m with H2010 Ultraflex Coaxial Cable



Danger!

Do not work on the antenna installation during thunderstorms!


Danger of death from electric shock!

- Do not carry out any work on the antenna installation or the antenna cable if there is a risk of lightning strike.
- Do not perform any work on the antenna installation if it is not possible to maintain the prescribed safety distance from exposed power lines or electrical substations.




10.6 DCF77 Simulated Output (-62 dBm)

Output signal: 77.5 kHz frequency
Signal level: -62 dBm
Connection type: BNC, female
Cable: shielded coax line



10.7 Time Code AM Output

Carrier frequency: 1 kHz (IRIG-B)
Signal outputs: Unbalanced sine wave-signal:
3 V_{pp} (MARK)
1 V_{pp} (SPACE) into 50 Ohm
Connector: BNC, female
Cable: shielded coax line



10.8 DC Power Supply Connector


Connector Type:	16pin DMC Connector
Terminal Functions:	+ DC in (positive potential of the operating voltage) – DC in (negative potential of the operating voltage)

Power Supply Specifications

Nominal Voltage:	U_N	=	48 V
Rated Voltage Range:	U_{max}	=	20-60 V
Rated Current:	I_N	=	22 mA
Max. Power:	P_{max}	=	10 W

Output Specifications

Max. Heat Output:	E_{therm}	=	36 kJ/h (34.13 BTU/h)
-------------------	-------------	---	-----------------------



10.9 AC/DC Power Supply Connector

Connection Type: 5pin DFK

Pin Assignment:


- 1: N/-
- 2: not connected
- 3: PE (Protective Earth)
- 4: not connected
- 5: L/+

Input Parameter

Nominal Voltage Range:	U_N	=	100-240 V $\sim$ 100-240 V $\equiv$
Max. Voltage Range:	U_{max}	=	85-264 V $\sim$ 90-264 V $\equiv$
Nominal Current:	I_N	=	0.15 A
Nominal Frequency Range:	f_N	=	50-60 Hz
Max. Frequency Range:	f_{max}	=	47-63 Hz
Inrush Current:	I_P	=	50 A @ 230 V AC

Output Parameter

Max. Power:	P_{max}	=	15 W
Max. Heat Emission:	E_{therm}	=	54.00 kJ/h (51.19 BTU/h)



Danger!

This equipment is operated at a hazardous voltage.

Danger of death from electric shock!




- This device must be connected by qualified personnel (electricians) only.
- Never handle exposed terminals or plugs while the power is on.
- All connectors must provide protection against contact with live parts in the form of a suitable plug body!
- Note: Always ensure that wiring is safe!
- Important: The device must be grounded by means of a connection with a correctly installed protective earth conductor (PE).

10.10 Fuse

The fuse protects against overload or short circuits and thus prevents damage to the installed power supply. The fuse is accessible from the front panel and can be replaced.

Technical Specification

Rated Voltage:	250 V
Shutter delay:	slow blow
Rated Current:	630 mA



Danger!

Danger of death due to electrical shock!

This equipment is operated at a hazardous voltage.



- The device must be disconnected from the mains! This is done using the physical power switch. Once the power switch is OFF, release the lock screws of the power supply connector and detach the connector.
- Disconnect all signal cables from the device, including antenna, fault message relay contact cables, and serial interfaces.
- Please note the information in the chapter "Important Safety Information -> Replacing the Fuse"

11 Technical Specifications GNS Receiver

Receiver:	Combined GPS / GLONASS / Galileo / BeiDou receiver Number of channels: 72 Frequency band: GNSS L1 1575.42 +- 10 MHz / 1602-1615 MHz
Antenna:	Type of antenna: Multi – GNSS L1 Antenna Antenna with Integrated Lightning Protection (see chapter "Mounting the antenna")
Time to Synchronization:	one minute with known receiver position and valid almanac 12 minutes if invalid battery buffered memory
Battery Backup:	storage of pulse configuration and important GNSS-system data in the internal RAM, backed-up by lithium battery lifetime of battery 10 years min.
Pulse Outputs:	three programmable outputs GNS165/DHS, GNS165/DAHS DC-insulated by optocouplers $U_{CEmax} = 55\text{ V}$, $I_{Cmax} = 50\text{ mA}$, $P_{tot} = 150\text{ mW}$, $V_{iso} = 5000\text{ V}$ pulse delay: t_{on} e.g. $20\text{ }\mu\text{sec}$ ($I_C = 10\text{ mA}$) t_{off} e.g. $3\text{ }\mu\text{sec}$ ($I_C = 10\text{ mA}$) GNS165/MOS/DHS, GNS165/MOS/DAHS DC-insulated by PhotoMOS relays $U_{max} = 250\text{ V AC/DC peak}$, $I_{max} = 150\text{ mA}$, $P_{tot} = 360\text{ mW}$, $V_{iso} = 1500\text{ V}$ pulse delay: t_{on} e.g. $0,18\text{ msec}$ ($I_{load} = 150\text{ mA}$) t_{off} e.g. $0,07\text{ msec}$ ($I_{load} = 150\text{ mA}$) default settings: all pulse outputs inactive mode of operation: 'if sync'
Accuracy of Pulses:	better than +-100nsec after synchronization and 20 minutes of operation better than +-3 μsec during the first 20 minutes of operation
Serial Ports:	3 independant asynchronous serial ports COM0 (RS-232) Baud Rate: 300 up to 19200 Framing: 7N2, 7E1, 7E2, 8N1, 8N2, 8E1, 801 COM1 (RS-232, optional RS-485) Baud Rate: 300 up to 19200 Framing: 7N2, 7E1, 7E2, 8N1, 8N2, 8E1, 801 COM2 (RS-485) Baud Rate: 300 up to 19200 Framing: 7N2, 7E1, 7E2, 8N1, 8N2, 8E1, 801 time string selectable for COM0, COM1 and COM2 possible stringtypes in chapter: Time Stings

	default settings: COM0: 19200, 8N1 COM1, COM2: 9600, 8N1 'standard Meinberg' time string per second mode of operation 'if sync'
Time Code	
Outputs:	modulated via BNC-connector: 3 V _{pp} (MARK), 1 V _{pp} (SPACE) into 50Ω unmodulated via 16-pin terminal: Field effect transistor with internal pull-up (1 kΩ) to +5 V Data of transistor: U _{ds_max} = 100 V, I _{d_max} = 150 mA, P _{max} = 250 mW TTL into 50Ω RS422
DCF77-Emulation:	AM-modulated 77.5 kHz carrier frequency usable as replacement for a DCF77 antenna output level approximately -55 dBm (unmodulated)
Power Requirements:	GNS165/DHS 20-60 V DC DC-isolation 1.5 kV DC GNS165/DAHS 100-240 V DC 100-240 V AC, 50-60 Hz Fuse: 630 mA
Dimension:	GNS165/DHS 105 mm x 85 mm x 104 mm (height x width x depth) GNS165/DAHS 105 mm x 125.5 mm x 104 mm (height x width x depth)
Connectors:	SMA connector for Multi-GNSS connection, AM modulated DCF77 output and modulated time code output 16-pole terminal block for connection of: - pulse outputs - power supply (GNS165DHS and GNS165/MOS/DHS only) DAHS, AQ/DAHS: 5pol. Screwterminal
Ambient Temperature:	0 ... 50°C
Humidity:	85% max.

11.1 Technical Specifications: 40 dB Multi GNSS Antenna

GPS L1 / GLONASS L1 / Galileo E1 / BeiDou B1 Frequency Band

GPS, GLONASS, Galileo, and BeiDou satellites do not hold a geostationary orbit, but circle the Earth once roughly every 12 hours. Satellites can only be received as long as there is nothing obstructing the line of sight between the antenna and the satellite. Detailed installation requirements can be found in the chapter **Antenna Installation**.

This active L1 antenna incorporates a high-performance antenna and low-noise amplifier in a weatherproof housing. The connected GPS/GLONASS receiver supplies the antenna with a 5.0 V DC voltage via the antenna cable.


A standard coaxial cable with 50 Ohm impedance can be used to connect the antenna to the receiver. The length of the cable between the antenna and receiver should not exceed 70 meters (H155, Low-Loss). A mounting kit is provided with the product as shipped.

Please refer to the data sheet, which can be downloaded here:

https://www.meinbergglobal.com/download/docs/other/pctel_gpst1gl.pdf

11.2 Technical Specifications: RV-76G GPS/GLONASS Antenna for Mobile Applications

Installation of the Antenna



Further Information on the Product

Detailed specifications are provided in the manufacturer's data sheet.

Source: *RV-76G_Catalog_V1.0_20130502 Data Sheet (Sanav)*

Download: https://www.meinbergglobal.com/download/docs/other/rv-76g_en.pdf

11.3 Technical Specifications: MBG-S-PRO Surge Protector

The MBG-S-PRO is a surge protector (Phoenix CN-UB-280DC-BB) for coaxial connections. It is patched directly into the antenna line and consists of a replaceable gas discharge tube that redirects the energy from the cable shielding to the ground potential when ignited. Connect the MBG-S-PRO using a ground conductor cable that is as short as possible.

The MBG S-PRO has no dedicated input/output polarity and no preferred installation orientation.



Phoenix CN-UB-280DC-BB

Features:

- Excellent RF Performance
- Multiple Strike Capability
- 20 kA Surge Protection
- Bidirectional Protection

Contents of Package:	Surge Protector with Mounting Bracket and Accessories
Product Type:	Surge Protector for Transmission and Receiver Devices
Construction Type:	In-Line Breaker
Connector Types:	Type-N, Female/Type-N, Female

The original product page of the supplier (see link) of the CN-UB-280DC-BB surge protector provides detailed specifications, as well as a variety of product-specific documents under the link below:

Data Sheet (Download):

https://www.meinbergglobal.com/download/docs/shortinfo/german/cn-ub-280dc-bb_pc.pdf

11.4 Connection Data DFMC-connector

Conductor cross section solid min.	0.2 mm ²
Conductor cross section solid max.	1.5 mm ²
Conductor cross section flexibel min.	0.2 mm ²
Conductor cross section flexibel max.	1.5 mm ²
Conductor cross section flexible, with ferrule, without plastic sleeve min.	0.25 mm ²
Conductor cross section flexible, with ferrule, without plastic sleeve max.	1.5 mm ²
Conductor cross section flexible, with ferrule, with plastic sleeve min.	0.25 mm ²
Conductor cross section flexible with ferrule, with plastic sleeve max.	0.75 mm ²
Conductor cross section AWG min.	24
Conductor cross section AWG max.	16
AWG according to UL/CUL min.	16
AWG according to UL/CUL max.	24

Specifications for ferrules

Ferrules without insulating collar,
according to DIN 46228-1

Cross-section: 0.25 mm²; length: 5 mm ... 7 mm
 Cross-section: 0.34 mm²; length: 7 mm
 Cross-section: 0.5 mm²; length: 8 mm ... 10 mm
 Cross-section: 0.75 mm²; length: 8 mm ... 10 mm
 Cross-section: 1 mm²; length: 8 mm ... 10 mm
 Cross-section: 1.5 mm²; length: 10 mm

Ferrules with insulating collar,
according to DIN 46228-4

Cross-section: 0.14 mm²; length: 8 mm
 Cross-section: 0.25 mm²; length: 8 mm ... 10 mm
 Cross-section: 0.34 mm²; length: 8 mm ... 10 mm
 Cross-section: 0.5 mm²; length: 8 mm ... 10 mm
 Cross-section: 0.75 mm²; length: 8 mm ... 10 mm

11.5 Time Strings

11.5.1 Meinberg Standard Time String

The Meinberg Standard Time String is a sequence of 32 ASCII characters starting with the <STX> (Start-of-Text) character and ending with the <ETX> (End-of-Text) character. The format is as follows:

<STX>D:dd.mm.yy;T:w;U:hh.mm.ss;uvxy<ETX>

The letters printed in italics are replaced by ASCII-formatted numbers, whereas the other characters are directly part of the time string. The groups of characters as defined below:

<STX>	Start-of-Text, ASCII code 02h sent with one-bit accuracy at the change of each second		
dd.mm.yy	The date:		
dd	Day of Month	(01–31)	
mm	Month	(01–12)	
yy	Year of the Century	(00–99)	
w	The day of the week		(1–7, 1 = Monday)
hh.mm.ss	The time:		
hh	Hours	(00–23)	
mm	Minutes	(00–59)	
ss	Seconds	(00–59, or 60 during leap second)	
uv	Clock status characters (depending on clock type):		
u:	'#'	GPS: Clock is in free-run mode (no exact synchronization)	
		PZF: Time frame not synchronized	
		DCF77: Clock has not synchronized since last reset	
	' '	(space, 20h)	
		GPS: Clock is synchronized (base accuracy is reached)	
		PZF: Time frame is synchronized	
		DCF77: Clock has synchronized since last reset	
v:	'*'	GPS: Receiver has not checked its position	
		PZF/DCF77: Clock currently running off XTAL	
	' '	(space, 20h)	
		GPS: Receiver has determined its position	
		PZF/DCF77: Clock is synchronized with transmitter	
x	Time zone indicator:		
	'U'	UTC	Universal Time Coordinated, formerly GMT
	' '	CET	European Standard Time, daylight saving disabled
	'S'	(CEST)	European Summertime, daylight saving enabled
y	Announcement of clock jump during last hour before jump enters effect:		
	'!'	Announcement of start or end of Daylight Saving Time	
	'A'	Announcement of leap second insertion	
	' '	(Space, 20h) nothing announced	
<ETX>	End-of-Text, ASCII code 03h		

11.5.2 SAT Time String

The SAT Time String is a sequence of 29 ASCII characters starting with the <STX> (start-of-text) character and ending with the <ETX> (end-of-text) character. The format is as follows:

<STX>*dd.mm.yy/w/hh:mm:ssxxxxuv*<ETX>

The letters printed in italics are replaced by ASCII-formatted numbers, whereas the other characters are directly part of the time string. The groups of characters are as defined below:

<STX>	Start-of-Text, ASCII code 02h sent with one-bit accuracy at the change of each second		
dd.mm.yy	The date:		
dd	Day of Month	(01–31)	
mm	Month	(01–12)	
yy	Year of the Century	(00–99)	
w	The day of the week (1 = Monday)		
hh:mm:ss	The time:		
hh	Hours	(00–23)	
mm	Minutes	(00–59)	
ss	Seconds	(00–59, or 60 during leap second)	
xxxx	Time zone indicator:		
	'UTC'	Universal Time Coordinated, formerly GMT	
	'CET'	European Standard Time, daylight saving disabled	
	'CEST'	European Summertime, daylight saving enabled	
u	Clock status characters:		
	'#'	Clock has not synchronized since last reset	
	' '	(Space, 20h) Clock has synchronized since last reset	
v	Announcement of clock jump during last hour before jump enters effect:		
	'!'	Announcement of start or end of Daylight Saving Time	
	' '	(Space, 20h) nothing announced	
<CR>	Carriage Return, ASCII code 0Dh		
<LF>	Line Feed, ASCII code 0Ah		
<ETX>	End-of-Text, ASCII code 03h		

11.5.3 NMEA 0183 String (RMC)

The NMEA 0183 RMC String is a sequence of 65 ASCII characters starting with the string '\$GPRMC' and ending with the characters <CR> (Carriage Return) and <LF> (Line Feed). The format is as follows:

```
$GPRMC, h h m m s s . f f , A , b b b b . b b , n , l l l l l . l l , e , 0 . 0 , 0 . 0 , d d m m y y , 0 . 0 , a * h h <CR><LF>
```

The letters printed in italics are replaced by ASCII-formatted numbers, whereas the other characters are directly part of the time string. The groups of characters are as defined below:

\$	Start character, ASCII code 24h sent with one-bit accuracy at the change of each second
GP	Talker ID, in this case "GP" for GPS
RMC	Message type ID, in this case "RMC"
h h m m s s . s s	The time: hh Hours (00–23) mm Minutes (00–59) ss Seconds (00–59, or 60 during leap second) ff Fractions of Seconds (1/10 ; 1/100)
A	Status (A = Time Data Valid, V = Time Data not Valid)
b b b b . b b	Geographical latitude of receiver position in degrees Leading characters padded by space characters (ASCII code 20h)
n	Latitudinal hemisphere, with the following characters possible: "N" North of Equator "S" South of Equator
l l l l l . l l	Geographical longitude of receiver position in degrees Leading characters padded by space characters (ASCII code 20h)
e	Longitudinal hemisphere, with following characters possible: "E" East of Greenwich Meridian "W" West of Greenwich Meridian
0 . 0 , 0 . 0	Speed over the ground in knots and track angle in degrees. With a Meinberg GPS clock, these values are always 0.0, With GNS clocks, the values are calculated by the receiver for mobile applications
d d m m y y	The date: dd Day of Month (01–31) mm Month (01–12) yy Year of the Century (00–99)
a	Magnetic Variation E/W
h h	Checksum (XOR of all characters except "\$" and "*")
<CR>	Carriage Return, ASCII code 0Dh
<LF>	Line Feed, ASCII code 0Ah

11.5.4 NMEA 0183 String (GGA)

The NMEA 0193 GGA String is a sequence of characters starting with the string "\$GPGGA" and ending with the characters <CR> (Carriage Return) and <LF> (Line Feed). The format is as follows:

```
$GPGGA, hhmmss.ff, bbbb.bbbbb, n, lllll.ll, e, A, vv, hhh.h, aaa.a, M,
ggg.g, M, , 0*cs<CR><LF>
```

The letters printed in italics are replaced by ASCII-formatted numbers, whereas the other characters are directly part of the time string. The groups of characters are as defined below:

\$	Start character, ASCII code 24h sent with one-bit accuracy at the change of each second
GP	Talker ID, in this case "GP" for GPS
GGA	Message type ID, in this case "GGA"
hhmmss.ss	The time: <i>hh</i> Hours (00–23) <i>mm</i> Minutes (00–59) <i>ss</i> Seconds (00–59, or 60 while leap second) <i>ff</i> Fractions of Seconds (1/10 ; 1/100)
bbbb.bbbbb	Geographical latitude of receiver position in degrees Leading characters padded by space characters (ASCII code 20h)
n	Latitudinal hemisphere, with the following characters possible: "N" North of Equator "S" South of Equator
lllll.lllll	Geographical longitude of receiver position in degrees Leading characters padded by space characters (20h)
e	Longitudinal hemisphere, with following characters possible: "E" East of Greenwich Meridian "W" West of Greenwich Meridian
A	Position fixed (1 = yes, 0 = no)
vv	Number of satellites used (0–12)
hhh.h	HDOP (Horizontal Dilution of Precision)
aaa.h	Mean Sea Level Altitude (MSL Altitude = WGS84 Altitude – Geoid Separation)
M	Meters (unit as fixed value)
ggg.g	Geoid Separation (WGS84 Altitude – MSL Altitude)
M	Meters (unit as fixed value)
cs	Checksum (XOR of all characters except "\$" and "*")
<CR>	Carriage Return, ASCII code 0Dh
<LF>	Line Feed, ASCII code 0Ah

11.5.5 NMEA 0183 String (ZDA)

The NMEA 0183 ZDA String is a sequence of 38 ASCII characters starting with the string "\$GPZDA" and ending with the characters <CR> (Carriage Return) and <LF> (Line Feed). The format is:

*\$GPZDA, hhmmss.ss, dd, mm, yyyy, HH, II *cs*<CR><LF>

ZDA - Time and Date: UTC, day, month, year, and local time zone.

The letters printed in italics are replaced by ASCII-formatted numbers, whereas the other characters are directly part of the time string. The groups of characters are as defined below:

\$	Start character, ASCII Code 24h sent with one-bit accuracy at change of second		
hhmmss.ss	UTC time:		
hh	Hours	(00–23)	
mm	Minutes	(00–59)	
ss	Seconds	(00–59, or 60 during leap s	
HH, II	The local time zone (offset to UTC):		
HH	Hours	(00–±13)	
II	Minutes	(00–59)	
dd, mm, yy	The date:		
dd	Day of Month	(01–31)	
mm	Month	(01–12)	
YYYY	Year	(0000–9999)	
cs	Checksum (XOR of all characters except "\$" and "*")		
<CR>	Carriage Return, ASCII code 0Dh		
<LF>	Line Feed, ASCII code 0Ah		

11.5.6 Uni Erlangen String (NTP)

The Uni Erlangen String (NTP) of a GPS clock is a sequence of 66 ASCII characters starting with the <STX> (start-of-text) character and ending with the <ETX> (end-of-text) character. The format is as follows:

```
<STX>dd.mm.yy; w; hh:mm:ss; voo:oo; acdfg i;bbb.bbbbn lll.lllle hhhhm<ETX>
```

The letters printed in italics are replaced by ASCII-formatted numbers, whereas the other characters are directly part of the time string. The groups of characters are as defined below:

<STX>	Start-of-Text, ASCII code 02h sent with one-bit accuracy at the change of each second		
dd.mm.yy	The date: <i>dd</i> Day of Month (01–31) <i>mm</i> Month (01–12) <i>yy</i> Year of Century (00–99)		
w	Day of the week (1–7, 1 = Monday)		
hh.mm.ss	The time: <i>hh</i> Hours (00–23) <i>mm</i> Minutes (00–59) <i>ss</i> Seconds (00–59, or 60 during leap second)		
v	-/+ sign of the offset of local timezone relative to UTC		
oo:oo	Offset of local time zone relative to UTC in hours and minutes		
ac	Clock status characters: a: '#' Clock has not synchronized since reset ' ' (Space, 20h) Clock has synchronized since reset c: '*' GPS receiver has not checked its position ' ' (Space, 20h) GPS receiver has determined its position		
d	Time zone indicator: 'S' CEST European Summertime, Daylight Saving Time enabled ' ' CET European Standard Time, Daylight Saving Time disabled		
f	Announcement of clock jump during last hour before jump enters effect: '!' Announcement of start or end of Daylight Saving Time ' ' (Space, 20h) nothing announced		
g	Announcement of clock jump during last hour before jump enters effect: 'A' Announcement of leap second insertion ' ' (Space, 20h) nothing announced		
i	Leap second insertion 'L' Leap second is currently to be inserted (only active in 60th second) ' ' (Space, 20h) No leap second to be inserted		
bbb.bbbb	Geographical latitude of receiver position in degrees Leading characters padded by Space characters (20h)		

n	Latitudinal hemisphere, with the following characters possible: 'N' North of Equator 'S' South of Equator
lll, llll	Geographical longitude of receiver position in degrees Leading characters padded by Space characters (20h)
e	Longitudinal hemisphere, with the following characters possible: 'E' East of Greenwich Meridian 'W' West of Greenwich Meridian
hhhh	Altitude above WGS84 ellipsoid in meters Leading characters padded by Space characters (20h)
<ETX>	End-of-Text, ASCII code 03h

11.5.7 Computime Time String

The Computime time string is a sequence of 24 ASCII characters, starting with the character **T** and terminated with the character **<LF>** (Line Feed, ASCII code 0Ah). The format is as follows:

T:*yy:mm:dd:ww:hh:mm:ss***<CR><LF>**

The letters printed in italics are replaced by ASCII numbers whereas the other characters are unalterable parts of the time string. The groups of characters as defined below:

T	Start character Sent with 1-bit accuracy at the start of the second.												
yy:mm:dd	The current date: <table><tr><td>yy</td><td>Year without century</td><td>(00–99)</td></tr><tr><td>mm</td><td>Month</td><td>(01–12)</td></tr><tr><td>dd</td><td>Day of the month</td><td>(01–31)</td></tr><tr><td>ww</td><td>Day of the week</td><td>(1–7, 1 = Monday)</td></tr></table>	yy	Year without century	(00–99)	mm	Month	(01–12)	dd	Day of the month	(01–31)	ww	Day of the week	(1–7, 1 = Monday)
yy	Year without century	(00–99)											
mm	Month	(01–12)											
dd	Day of the month	(01–31)											
ww	Day of the week	(1–7, 1 = Monday)											
hh:mm:ss	The current time: <table><tr><td>hh</td><td>Hours</td><td>(00–23)</td></tr><tr><td>mm</td><td>Minutes</td><td>(00–59)</td></tr><tr><td>ss</td><td>Seconds</td><td>(00–59, or 60 during leap second)</td></tr></table>	hh	Hours	(00–23)	mm	Minutes	(00–59)	ss	Seconds	(00–59, or 60 during leap second)			
hh	Hours	(00–23)											
mm	Minutes	(00–59)											
ss	Seconds	(00–59, or 60 during leap second)											
<CR>	Carriage Return (ASCII code 0Dh)												
<LF>	Line Feed (ASCII code 0Ah)												

11.5.8 SYSPLEX-1 Time String

The SYSPLEX-1 time string is a sequence of 16 ASCII characters starting with the <SOH> (Start-of-Header) ASCII control character and terminated with the <LF> (Line Feed, ASCII code 0Ah) character.



Important!

To ensure that the time string can be correctly output and displayed through any given terminal program, a singular "C" (not include quotation marks) must be input.

The format is:

<SOH>*ttt*:*hh*:*mm*:*ssq*<CR><LF>

The letters printed in italics are replaced by ASCII numbers whereas the other characters are part of the time string. The groups of characters as defined below:

<SOH>	Start-of-Header, ASCII code 01h sent with one-bit accuracy at the change of each second		
ddd	Day of Year	(001–366)	
hh:mm:ss	Current time:		
hh	Hours	(00–23)	
mm	Minutes	(00–59)	
ss	Seconds	(00–59, or 60 during leap second)	
q	Quality Indicator	Space (ASCII code 20h) "?" (ASCII code 3Fh)	Time Sync (GPS Lock) No Time Sync (GPS Fail)
<CR>	Carriage Return (ASCII code 0Dh)		
<LF>	Line Feed (ASCII code 0Ah)		

11.5.9 Format of the SPA Time String

The ABB SPA Time String is a sequence of 32 ASCII characters starting with the characters ">900WD" and ending with the <CR> (Carriage Return) character. The format is:

>900WD:*jj-mm-tt_hh.mm;ss.fff*:cc<CR>

The letters printed in italics are replaced by ASCII numbers whereas the other characters are part of the time string. The groups of characters as defined below:

jj-mm-tt	the current date:		
jj	year of the century	(00..99)	
mm	month	(01..12)	
tt	day of month	(01..31)	
–	Space	(ASCII-code 20h)	
hh.mm;ss.fff	the current time:		
hh	hours	(00..23)	
mm	minutes	(00..59)	
ss	seconds	(00..59, or 60 while leap second)	
fff	milliseconds	(000..999)	
cc	Checksum. EXCLUSIVE-OR result of the previous characters, displayed as a HEX byte (2 ASCII characters 0..9 or A..F)		
<CR>	Carriage Return	ASCII Code 0Dh	

11.5.10 RACAL Standard Time String

The RACAL Standard Time String is a sequence of 16 ASCII characters started by a X character and terminated by the <CR> (Carriage Return, ASCII code 0Dh) character. The format is as follows:

XGUyyymmddhhmmss<CR>

The letters printed in italics are replaced by ASCII-formatted numbers, whereas the other characters are directly part of the time string. The groups of characters are as defined below:

X	Start character, ASCII code 58h Sent with one-bit accuracy at the change of each second		
G	Control character, ASCII code 47h		
U	Control character, ASCII code 55h		
yyymmdd	Current date:		
	yy	Year of Century	(00–99)
	mm	Month	(01–12)
	dd	Day of Month	(01–31)
hh:mm:ss	Current time:		
	hh	Hours	(00–23)
	mm	Minutes	(00–59)
	ss	Seconds	(00–59, or 60 during leap second)
<CR>	Carriage Return, ASCII code 0Dh		

11.5.11 Meinberg GPS Time String

The Meinberg GPS Time String is a sequence of 36 ASCII characters starting with the <STX> (Start-of-Text) character and ending with the <ETX> (End-of-Text) character. Unlike the Meinberg Standard Time String, the Meinberg GPS Time String does not carry any local time zone or UTC data; it simply carries the direct GPS time without any conversion into UTC. The format is as follows:

<STX>D:dd.mm.yy;T:w;U:hh.mm.ss;uvGy;lll<ETX>

The letters printed in *italics* are replaced by ASCII-formatted numbers, whereas the other characters are directly part of the time string. The groups of characters as defined below:

<STX>	Start-of-Text, ASCII code 02h
dd.mm.yy	The date: <i>dd</i> Day of Month (01–31) <i>mm</i> Month (01–12) <i>yy</i> Year of the (00–99) Century
w	the day of the week (1–7, 1 = Monday)
hh.mm.ss	the current time: <i>hh</i> Hours (00–23) <i>mm</i> Minutes (00–59) <i>ss</i> Seconds (00–59, or 60 while leap second)
uv	Clock status characters: <i>u</i> : ' #' Clock is in free-run mode (no exact synchronization) ' ' (Space, 20h) Clock is synchronized (base accuracy is achieved) <i>v</i> : ' * ' Receiver has not checked its position ' ' (Space, 20h) Receiver has determined its position
G	'GPS time' time zone indicator
y	Announcement of clock jump during last hour before jump enters effect: before discontinuity comes in effect: 'A' Announcement of leap second insertion ' ' (Space, 20h) nothing announced
lll	Number of leap seconds between UTC and GPS Time (UTC = GPS time + number of leap seconds)
<ETX>	End-of-Text, ASCII code 03h

11.5.12 ION Time String

The ION time string is a sequence of 16 ASCII characters starting with the <SOH> (Start of Header, ASCII code 01h) ASCII control character and ending with the <LF> (Line Feed, ASCII code 0Ah) character. The format is as follows:

<SOH>*ddd:hh:mm:ssq*<CR><LF>

The letters printed in italics are replaced by ASCII-formatted numbers, whereas the other characters are directly part of the time string. The groups of characters as defined below:

<SOH>	Start of Header (ASCII code 01h) sent with one-bit accuracy at the change of each second		
ddd	Day of Year	(001–366)	
hh:mm:ss	Current time:		
hh	Hours	(00–23)	
mm	Minutes	(00–59)	
ss	Seconds	(00–59, or 60 while leap second)	
q	Quality Indicator	Space (ASCII code 20h) "?" (ASCII code 3Fh)	Time Sync (GPS Lock) No Time Sync (GPS Fail)
<CR>	Carriage Return (ASCII code 0Dh)		
<LF>	Line Feed (ASCII code 0Ah)		

11.5.13 ION Blanked Time String

The ION Blanked time string is a sequence of 16 ASCII characters starting with the <SOH> (Start of Header, ASCII code 01h) ASCII control character and ending with the <LF> (Line Feed, ASCII code 0Ah) character. The format is as follows:

<SOH>ddd:hh:mm:ssq<CR><LF>



Important!

The blanking interval of is 2 minutes and 30 seconds long and is added every 5 minutes.

The letters printed in *italics>* are replaced by ASCII-formatted numbers, whereas the other characters are directly part of the time string. The groups of characters as defined below:

<SOH>	Start of Header (ASCII code 01h) sent with one-bit accuracy at the change of each second		
ddd	Day of Year		(001–366)
hh:mm:ss	Current time:		
hh	Hours	(00–23)	
mm	Minutes	(00–59)	
ss	Seconds	(00–59, or 60 while leap second)	
q	Quality Indicator	Space (ASCII code 20h) "?" (ASCII code 3Fh)	Time Sync (GPS Lock) No Time Sync (GPS Fail)
<CR>	Carriage Return (ASCII code 0Dh)		
<LF>	Line Feed (ASCII code 0Ah)		

11.5.14 IRIG-J Timecode

The IRIG-J timecode consists of a string of ASCII characters sent in "701" format, i.e.,:

- 1 Start Bit
- 7 Data Bits
- 1 Parity Bit (odd)
- 1 Stop Bit

The on-time marker of the string is the leading edge of the start bit. The timecode consists of 15 characters, sent once per second at a baud rate of 300 or greater. The format is as follows:

`<SOH>DDD:HH:MM:SS<CR><LF>`

The letters printed in italics are replaced by ASCII-formatted numbers, whereas the other characters are directly part of the time string. The groups of characters are as defined below:

<code><SOH></code>	"Start of Header" (ASCII code 01h)
DDD	Day of the year (ordinal date, 1–366)
HH, MM, SS	Time of the start bit, specified in hours (HH), minutes (MM), seconds (SS)
<code><CR></code>	"Carriage Return" (ASCII code 0Dh)
<code><LF></code>	"Line Feed" (ASCII code 0Ah)

11.6 Oscillator specifications

Oscillators available for Meinberg Reference Clocks / Time Servers:
TCXO, OCXO LQ /SQ/HQ/DHQ

	TCXO	OCXO LQ	OCXO SQ	OCXO HQ	OCXO DHQ
short term stability ($\tau = 1 \text{ sec}$)	$2 \cdot 10^{-9}$	$1 \cdot 10^{-9}$	$2 \cdot 10^{-10}$	$5 \cdot 10^{-12}$	$2 \cdot 10^{-12}$
accuracy of PPS (pulse per sec)	$< \pm 250 \text{ ns}$	$< \pm 250 \text{ ns}$	$< \pm 100 \text{ ns}$	$< \pm 100 \text{ ns}$	$< \pm 100 \text{ ns}$
phase noise	1Hz -60dBc/Hz 10Hz -90dBc/Hz 100Hz -120dBc/Hz 1kHz -130dBc/Hz	1Hz -60dBc/Hz 10Hz -90dBc/Hz 100Hz -120dBc/Hz 1kHz -130dBc/Hz	1Hz -75dBc/Hz 10Hz -110dBc/Hz 100Hz -130dBc/Hz 1kHz -140dBc/Hz	1Hz < -85dBc/Hz 10Hz < -115dBc/Hz 100Hz < -130dBc/Hz 1kHz < -140dBc/Hz	1Hz < -80dBc/Hz 10Hz < -110dBc/Hz 100Hz < -125dBc/Hz 1kHz < -135dBc/Hz
accuracy free run, one day	$\pm 1 \cdot 10^{-7}$ $\pm 1 \text{ Hz}$ (Note1)	$\pm 2 \cdot 10^{-8}$ $\pm 0.2 \text{ Hz}$ (Note1)	$\pm 1.5 \cdot 10^{-9}$ $\pm 15 \text{ mHz}$ (Note1)	$\pm 5 \cdot 10^{-10}$ $\pm 5 \text{ mHz}$ (Note1)	$\pm 1 \cdot 10^{-10}$ $\pm 1 \text{ mHz}$ (Note1)
accuracy, free run, 1 year	$\pm 1 \cdot 10^{-6}$ $\pm 10 \text{ Hz}$ (Note1)	$\pm 4 \cdot 10^{-7}$ $\pm 4 \text{ Hz}$ (Note1)	$\pm 1 \cdot 10^{-7}$ $\pm 1 \text{ Hz}$ (Note1)	$\pm 5 \cdot 10^{-8}$ $\pm 0.5 \text{ Hz}$ (Note1)	$\pm 1 \cdot 10^{-8}$ $\pm 0.1 \text{ Hz}$ (Note1)
accuracy GPS-synchronous, average 24h	$\pm 1 \cdot 10^{-11}$	$\pm 1 \cdot 10^{-11}$	$\pm 5 \cdot 10^{-12}$	$\pm 1 \cdot 10^{-12}$	$\pm 1 \cdot 10^{-12}$
accuracy of time free run, 1 day	$\pm 4.3 \text{ ms}$	$\pm 865 \mu\text{s}$	$\pm 65 \mu\text{s}$	$\pm 10 \mu\text{s}$	$\pm 4.5 \mu\text{s}$
accuracy of time free run, 1 year	$\pm 16 \text{ s}$	$\pm 6.3 \text{ s}$	$\pm 1.6 \text{ s}$	$\pm 788 \text{ ms}$	$\pm 158 \text{ ms}$
temperature dependant drift free run	$\pm 1 \cdot 10^{-6}$ (-20...70°C)	$\pm 2 \cdot 10^{-7}$ (0...60°C)	$\pm 1 \cdot 10^{-7}$ (-10...70°C)	$\pm 1 \cdot 10^{-8}$ (5...70°C)	$\pm 2 \cdot 10^{-10}$ (5...70°C)

Note 1: The accuracy in Hertz is based on the standard frequency of 10 MHz.

For example: Accuracy of TCXO (free run one day) is $\pm 1 \cdot 10^{-7} \cdot 10 \text{ MHz} = \pm 1 \text{ Hz}$

The given values for the accuracy of frequency and time (not short term accuracy) are only valid for a constant ambient temperature! A minimum time of 24 hours of GPS-synchronicity is required before free run starts.

12 Meinberg Device Manager


The program serves the configuration of Meinberg Radio Clocks. The software can be run on the operating systems Windows 7 or higher.

Documentation:

<https://www.meinbergglobal.com/download/docs/manuals/english/meinberg-device-manager.pdf>

Download:


<https://www.meinbergglobal.com/english/sw/mbg-devman.htm>



A connection between the system and the program can be produced by serial port. The configurations are described in the "Meinberg Device Manager" documentation.

Connection

The PC should have generated an automatic connection to the clock, select the tab "Search Device". Alternatively, you can use the button "Add Device" to generate a connection to the clock by using the same configure (Port / Baud / Framing).




The "Add Device" dialog box is shown with the following settings:

- Device Type: Other...
- Connection Type: Serial
- Serial Port: COM7
- Baudrate: 19200
- Framing: 8N1
- Custom Alias: GPS165
- Custom Group: Custom Group 1

Buttons: OK, Cancel

Configuration



The "Device Configuration" window is shown with the "Serial Ports" tab selected. The "Satellites" tab is also visible.

Serial Ports Settings

COM0 Baud Rate: 19200
COM0 Framing: 8N1
COM0 String Type: Meinberg Standard
COM0 Mode: Per second

COM1 Baud Rate: 9600
COM1 Framing: 8N1
COM1 String Type: Meinberg Standard
COM1 Mode: Per second

COM2 Baud Rate: 9600
COM2 Framing: 8N1
COM2 String Type: Meinberg Standard
COM2 Mode: Per second

Satellites Status

Status Filter: OK

SVNO	Elevation	Azimuth	Doppler	Status
5	50°	214°	-2088 Hz	OK
7	30°	65°	-2755 Hz	OK
8	12°	44°	331 Hz	OK
13	62°	291°	1597 Hz	OK
15	29°	235°	3071 Hz	OK
21	11°	319°	-96 Hz	OK
28	45°	141°	1926 Hz	OK
30	63°	71°	-1418 Hz	OK

SVNO: -
Elev.: -
Azim.: -

Buttons: Apply All & Close, Revoke All, Cancel & Close

With "Configure Device" various configurations can be carried out on the system. Please note that any changes you make in the settings must always be confirmed with the "Apply Configuration" button. Use the "Restore Configuration" button to reset all settings back to their default values. For more information, please refer to the Meinberg Device Manager manual.

13 RoHS Conformity

Conformity with EU Directive 2011/65/EU (RoHS)

We hereby declare that this product is compliant with the European Union Directive 2011/65/EU and its delegated directive 2015/863/EU "Restrictions of Hazardous Substances in Electrical and Electronic Equipment" and that no impermissible substances are present in our products pursuant to these Directives.

We warrant that our electrical and electronic products sold in the EU do not contain lead, cadmium, mercury, hexavalent chromium, polybrominated biphenyls (PBBs), polybrominated diphenyl ethers (PBDEs), bis(2-ethylhexyl)phthalat (DEHP), benzyl butyl phthalate (BBP), dibutyl phthalate (DBP), or diisobutyl phthalate (DIBP) above the legal limits.



15 Declaration of Conformity for Operation in the United Kingdom

UK Declaration of Conformity

Doc ID: GNS165DHS / GNS165DAHS-May 8, 2024

Manufacturer

Meinberg Funkuhren GmbH & Co. KG
Lange Wand 9
31812 Bad Pyrmont
Germany

declares that the product

Product Designation

GNS165DHS / GNS165DAHS

to which this declaration relates, is in conformity with the following standards and provisions of the following regulations under British law:

Radio Equipment Regulations 2017
(as amended)
SI 2017/1206

ETSI EN 303 413 V1.2.1 (2021-04)

Electromagnetic Compatibility
Regulations 2016 (as amended)
SI 2016/1091

ETSI EN 301 489-1 V2.2.3 (2019-11)
ETSI EN 301 489-19 V2.2.1 (2022-09)
EN IEC 61000-6-2:2019
EN IEC 61000-6-3:2021
EN 55032:2015/AC:2016/A11:2020/A1:2020
EN 55035:2017/A11:2020

Electrical Equipment (Safety)
Regulations 2016 (as amended)
SI 2016/1101

EN IEC 62368-1:2020/A11:2020


The Restriction of the Use of Certain
Hazardous Substances in Electrical and
Electronic Equipment Regulations 2012
(as amended)
SI 2012/3032

EN IEC 63000:2018

Bad Pyrmont, Germany, dated May 8, 2024

Aron Meinberg
Quality Management


Meinberg Funkuhren GmbH & Co. KG
Lange Wand 9
31812 Bad Pyrmont



GNS165_DAHS_QSG_080424